

Polymer Decorations**180°C****150 sec****Important**

The polymer decorations will become malleable when pressed.

After pressing remove and place under a heavy object while it cools to ensure the product remains flat.

Wooden Decorations**190°C****90 sec****Important**

The wooden decorations may have retained small amounts of moisture.

After pressing remove and place under a heavy object while it cools to ensure the product remains flat.

Frosted Acrylic Decorations**190°C****60 sec****Important**

The frosted acrylic decorations are designed to have sign vinyl applied to them but you can print using dye sublimation.

After pressing the paper will probably stick to the surface but this can be removed by soaking the decoration in water. Then remove the paper and if any paper residue remains use a white topped scourer.

After pressing remove and place under a heavy object while it cools to ensure the product remains flat.